



ATC LIGHT SIGNALS

1. Introduction

Use air traffic control light signals from the following table to control aircraft and the movement of vehicles, equipment and personnel on the manoeuvring area when radio communications cannot be employed.

Do not request an aircraft to acknowledge a transmission by turning the navigation lights on and off.

This article is not applicable for the IVAO Network for a pilot or an air traffic controller.
The IVAO interfaces are not compatible with the generation of these signals.

This documentation has only been made for information and the theoretical exam program.

2. Table

Color and type of signal	Aircraft on the ground	Aircraft in flight	Movement of vehicles
Steady green	Cleared for take-off	Cleared to land	Not Applicable
Flashing green	Cleared to taxi	Return for landing	Cleared to cross Proceed; go
Steady red	Stop	Give way to other aircraft and continue circling	Stop Hold your position
Flashing red	Taxi clear of landing area or runway in use	Aerodrome unsafe Do not land	Vacate the runway immediately
Flashing white	Return to starting point on the aerodrome	Not applicable	Return to starting point on the aerodrome

ATC light signals	Version 1.1	5 July 2015	Page 1
© IVAO HQ training department	Training Documentation Manager Erwan L'hotellier		